

GENERAL USE

Ensure vehicle roof is clean and free of grease, wax, polish and ice.

Ensure surface of magnets are free from grease and grit.

Situate sign in central position ensuring all magnets make maximum contact with surface.

Remove sign prior to washing vehicle.

In adverse weather conditions such as very cold weather, strong winds, remove signs from vehicle.

POSITIONING SIGN ON VEHICLE

Rest sign on its rear edge placing hands under the two front innermost nylon fixing bolts.

Lower gently into position, taking care not to drop

REMOVING SIGN FROM VEHICLE

Position your hands under the two front innermost nylon fixing bolts and tilt backwards taking care not to jerk sharply.

Lift clear.